

AQUA-TITE[®] Green

AQUA-TITE GREEN Instructions

1. Apply Aqua-Tite Green in well-ventilated area. Combustible liquid. Keep away from heat and open flames during application.
2. Make sure the fabric is clean and completely dry before treating. Remove dust and dirt by brushing.
3. Aqua-Tite Green can be applied by spray/mist, brush, or roller. Apply evenly and thoroughly without run-off. Fabric needs to be wetted-out evenly, do not saturate. Protect areas not intended for treatment from over spray or run-off. It is recommended to use approved spray applicator to achieve reliable results. Applicator should be cleaned with water.
4. Allow treated fabric to dry for 48-72 hours. Best results occur when treated fabric is exposed to hot sun for 2-3 days to fully dry and cure. Do not store or expose to moisture, rain or dew during this time.
5. Aqua-Tite Green is best applied in warm weather settings.